



ENGINE RUNNING GUIDELINES

OFFICIAL NOTICE Ref: EN010

U12.7 : Engines must not be run in the pits, awnings or paddock

The Chief Scrutineer only, may permit a competitor start there engine in a designated area only as identified by the Chief Scrutineer.

Designated area will be in parc ferme.

- 1:** Run area will be marked out signed and fencing on both sides.
- 2:** Engines will not be run before 10am on race day.
- 3:** Two karts only may be run at any one time and only inside the box.
- 4:** Only one driver and one mechanic per kart.
- 5:** Under no circumstances are Karts to be run outside the box you must wait until a space is clear.
- 6:** Engines can be run on the ground or on the trolley but safety is paramount.
 - 6a:** On the ground, driver must be seated and in control of the kart, kart must not be lifted when running, all four wheels firmly seated on the ground for the duration on the engine test.
 - 6b:** On trolleys, drive wheels will be facing the wall of the running bay you are responsible for your safety of yourself and others around the bay; you are reminded non gearbox when running the drive wheels are from the start continually running you must ensure no person is near these wheels.
- 7:** The engine **must only be run** for a maximum of ten seconds.
- 8:** You are allowed two sharp bursts in those ten seconds. That means open the throttle and close straight away it does not mean the throttle is open for any prolonged time.